

RIMMERS™

Slim I
RIPPLED RIMMING PLUG
WITH REMOTE CONTROL



SPIRAL NECK DESIGN
FOR ADDED
INCREASED STIMULATION

INTERNAL ROTATING BALLS

PREMIUM
SILICONE

POWERFUL
VIBRATION


USB
RECHARGEABLE

1

RIMMERS™

Slim I | RIPPLED RIMMING PLUG WITH REMOTE CONTROL

INSTRUCTIONS




Power On Plug:

Press power button on base of the plug, symbol lights up. The plug is now in standby mode. You can continue pressing the power button to cycle through the vibration and rotations settings simultaneously without the remote if desired.



Power On Remote:

Press power button  on remote. Remote will activate and all buttons will light up.

Press and hold power button  for 3 seconds on remote to shut off remote after use.

2


RIMMERS™


To Change Vibration Speeds and Functions of Plug:

Press left  button of wireless remote to activate vibration.


Press repeatedly to cycle through the 7 modes of vibration:

- Low Speed
- Medium Speed
- High Speed
- Function 1
- Function 2
- Function 3
- Function 4


Press and hold the left  button for 3 seconds to stop vibration.



To Change Speeds and Functions of Rotating Beads:

Press  button on wireless remote. Continue to press to cycle through the 4 modes of rotation:

- Low Speed
- Medium Speed
- High Speed
- Alternating Directions


Press and hold the right  button for 3 seconds to stop rotation.



3

RIMMERS™

SPECIFIC CONTROLLER FUNCTIONS:



4

RIMMERS™

**Power Off Plug:**

Press and hold the power button to quickly shut off the plug.

To Charge:

Connect to charger & plug in. Power symbol will blink while charging, then remain lit once fully charged. Charging times may vary depending on the voltage output of the power source. Plug takes 2 hours to charge and holds the charge for 1 hour.

TECHNICAL SPECS

Charging time:	2 hours
Running time:	1 hour
Vibrating functions/modes:	Rotating beads: 3 speeds + back and forth rotating Vibrator: 3 speeds + 4 patterns, 7 frequencies total
Battery type:	500mAh
Voltage:	3.7V
Remote control range:	25ft
Waterproof (category):	IPX6



BODY SAFE



WATER PROOF



WIRELESS CONTROLLER



PREMIUM SILICONE



USB RECHARGEABLE



POWERFUL VIBRATION

5

RIMMERS™

CARE INSTRUCTIONS

1. Wash plug with warm water and antibacterial toy cleaner.
2. Pat dry with a soft cloth. Product should be dry before storing.
3. Wipe remote with a damp cloth and small amount of toy cleaner as needed.
4. Store separately from toys made of other materials in a cool, dry location.

ALSO AVAILABLE FROM RIMMERS



Slim R
SMOOTH RIMMING PLUG
AF932



Slim M
CURVED RIMMING PLUG
AF934

RIMMERSTOYS.COM

This product is sold as a novelty only. No medical claims are warranted or implied by the use of this product. Use that has an adverse effect on any function of the human body is prohibited. To avoid injury or aggravation of pre-existing conditions, this product should not be used on bruised, swollen, or inflamed areas including skin lacerations. Discontinue use immediately if irritation or discomfort occurs. Rimmers, Huntington Beach, CA 92649

RIMMERS is a registered trademark of XR Brands
US Pat. D810,313



PLAY HARD.